


USER MANUAL (English)

VIDEO DOOR PHONE SYSTEM

Item No. : 14215



The design and specifications can be changed without notice to users.
Copyright of this manual is reserved.


Version 2.0.1.2.02.27

ENTRY VUE
video intercom systems


CONTENTS

1. Parts and Functions	1
2. Terminal Descriptions	1
3. Door Station Mounting	2
4. System Connection	3
5. Door Lock Connections	5
6. Door Station Configurations	7
7. Specifications	20

1. Parts and Functions




2. Terminal Descriptions



- +12V: 12VDC power output.
- LK-(GND): Power ground.
- LK+(COM): Common contact of the Relay .
- NO.:Normally open contact of the Relay
(Refer to DT technical guide for Lock connection detail informations).
- EB+: Exit button connection port.
- EB-: Exit buton connection port.
- JP-LK: For electronic lock safety type setting(refer to Door Station Lock Connections).
- T/R-: USB-RS485 communication terminal negative.
- T/R+: USB-RS485 communication terminal positive.
- Bus(L1,L2): non-polarity bus line.


3. Door Station Mounting



-2-


4. System Connection

Basic IN-OUT Wiring:



-3-

Multi Door Stations Wiring:




5. Door Lock Connections

1. Internal Power Supply Mode


Use the power of the system to supply for the electronic lock, so that the lock can be connected to the door station directly, without an additional power supply for the electronic lock. Note that the door station can only output 12Vdc power, therefore the kind of lock is limited.

- The rated power of the lock must be less than 12Vdc 300mA when using internal power supply mode.
- The GND must connect to the negative of the lock, and the COM connect to the positive .
- Jumper set to 1-2 position for Power-off-to-Unlock safety type (Normally closed mode); set to 2-3 position for Power-on-to -Unlock type (Normally open mode).
- If different unlocking time is needed to be configured, change the Unlock Timing on door station.(In debug state,press [1 #] --> [1] Installer Setup--> [2]Unlock Timing)

A. Connection for Power-on-to-Unlock type:



B. Connection for Power--off-to-Unlock type:




2. External Power Supply Mode

When the electronic lock is over 12 Vdc, additional power supply for the lock is needed.

- The power supply for the lock must be less than 48Vdc 1.5A.
- The Jumper must be removed when using external power supply. The default setting is Power-on-to-Unlock type(Normally open mode), if use Power-off-to-Unlock type, change the Unlock Relay mode to Normally closed mode .
- If different unlocking time is needed to be configured, change the Unlock Timing on door station. (In debug state, press [1 #] --> [1] Installer Setup--> [2]Unlock Timing)


C. Connection for Power-to-Unlock type:



set to Normally Open on the Unlock Relay mode (default)

Note: Cut off this line when using external power supply

D. Connection for Power--off-to-Unlock type:



set to Normally Closed on the Unlock Relay mode

Note: Cut off this line when using external power supply


6. Door Station Configurations

1. About room code(address):

Room Code(also called room address) is a code assigned to each monitor, to identify different monitors; each monitor have a unique room code in one building.The room Code is stored in each Monitor's inner EEPROM memory, and does not lose even the monitor is power off.

2. About Debug State:

The Debug State is your starting point for using all the applications on DMR18.



3. About Debug Tools:

During working at Debug State,press "1#" to enter tools page,Debug Tools overviews is shown as below:




Table 1 :

Item	Submenu
1. Installer Setup	1. ID Code [0] 2. Unlock Timing [05] 3. Unlock Output [0] 4. Card Memory [0] 5. Doorplate Mode 6. Audio Options ... 7. Parameters ... 8. Installer Code ... 9. Default ...
2. Setup	1. Language [1] 2. Tone Select [03] 3. Tone Volume [08] 4. Unlock Code [1111] 5. Display Mode 6. Clock ... 7. Setup Code ... 8. About ... 9. Default ...
3. Card Manage	1. Add Card ... 2. Delete By Card 3. Delete By M.code 4. Cards Information 5. Format
4. Online Monitors	To search the online monitors, input the monitor code number to search
5. Online Devices	To search the online door stations. Max.4 door station can be searched
6. Voltage Measure	To check the voltage of the monitor, note that the monitor must be online.

Basic Tools Detail :

Table 2 (Installer Setup) :

Item	Description	Factory Set
ID Code	If only one door station is installed in this building, set to 0 ; If multi door stations are installed, primary door station must be set to 0, and other slave door stations must be set from 1 to 3. Note that max. 4 door stations are available in one building	[0] Single
Unlock Timing	To set the time that how long the door keeps open when door is released. Range from 01 to 99 seconds.	[05] 5 Seconds
Unlock Output	To set the unlock mode to match the corresponding lock. Range from 0 to 1. 0: Power-on-to-Unlock Mode(Normally Open Mode) 1: Power-off-to-Unlock Mode(Normally Closed Mode)	0
Card Manage	To set the card location. If set to 0, the card is saved in door station. If set to 1, the card is saved in DT-IPC	0
Doorplate Mode	To set the calling mode. If set to 0, it's the auto mode, that means the calling will be activated directly after inputting 2 digits code. If set to 1, it's the manual mode, that means you should press "#" button to activate the calling after inputting the code.	[0] Auto mode
Audio Options ...	To set talking mode, when cutting voice or mixed voice appears, set to 1. DS-IM talking: set the voice matching between DoorStation and Indoor Monitor DS-NT talking: set the voice matching between Door Station and Guard Unit	0
Parameters ...	To show the parameters, please refer to table 2.1	
Installer Code ...	To change door station administrator code	[66666666]
Default ...	Note this operation is irreversible. Once restore is activated, all parameters will return to factory default setting except the information of access card.	

Table 2.1(Parameters):

Item	Description	Factory Set
Monitor Timing	To show the monitor time, Range from 6s to 600s	30s
Switch Timing	To show the surveillance time for each Door Station or CCTV camera.Range from 6s to 600s	40s
Wait Timing	To show the calling wait time, Range from 10s to 600s	30s
Talk Timing	To show the limitation time of talking, Range from 10s to 600s	90s
Monitor & Speak	To enable Indoor Monitor under monitoring state can speak to Door Station at same time. If set to 1, talk enabled; set to 0, disabled.	
Monitor & Unlock	To enable Monitors under monitoring state can open the door at the same time.If set to 0, unlock function is disabled; Set to 1, unlock is enable; Set to 2,unlock is enable and close at once; Set to 3, unlock is enable and close in 5s.	[1]
Ring Numbers	To show ring times when door station calls monitor. 4 options for choice. If set to 0, ring once. If set to 1, ring twice. If set to 2, ring three times. If set to 3,cycle ring.	[1]
NameList Display Mode	To show the namelist display mode.If set to 0, it's the DT-Config display mode.If set to 1, it's the Simulate display mode	[0]
Working Mode	To show the working mode. If set to 0, it's the apartment system mode. If set to 1,it's the villa mode.	[0]

Note : This section is set on DT-Config software,for more detail informations, please refer to the DT-Config software user instructions.

Table 3 (Setup) :

Item	Description	Factory Set
Language	To change language.the code format is 4 digits. Please refer to part 5,section 10 (change door station language) for more detail informations.	01
Tone Select	Select the chime of Door Station in calling wait state, 12 chord tunes are available, key in 01 to 12 to select.	03
Tone Volume	Adjust the tone volume for dooor station in calling. Range from 01~15	08
Unlock Code	To change unlock code in Common Code Unlock mode, in 4-digits format. 1111 is the default unlock code.	[1111]
Display Mode	To select the Door Station screen menu .If set to 0, the screen displays the visitor's image when talking. If set to 1,the screen displays icons when talking.	[0]
Clock ...	To set date and time. Date format:if set to 0,date format is DD/MM/YY, if set to 1,date format is MM/DD/YY. Time format: if set to 0, time format is 24 hour standard.If set to 1,time format is12 hour standard.	
Setup Code	To change the Program Code.	[88888888]
About ...	1. Hardware version--To show the Door Station (including ACS) hardware information 2. Software version--To show the Door Station (including ACS) software information 3. Manufacture Date--To show the manufacturing date 4. Dialing Counts--To show the call operation counts 5. Calls Counts--To show the established calling counts 6. Unlock Counts--To show the unlock operation counts 7. Standby Voltage--To show the voltage that the door station in standby. 8. Working Voltage--To show the voltage that the door station in working. 9. Video Standard--PAL or NTSC standard 10. UI_CODE--To show the UI byte counts and check box 11. MCM-VER--To show the version and language for MCM 12. Updated--To show the updated time for UI	
Default ...	Restore all Setup parameters to factory default setting, Please note that this operation is an irreversible	

Table 4 (Card Manage):

Item	Description	Factory Set
Add Card ...	To add the user card	
Delete By Card	To delete card by user card	
Delete By M.code	To delete card by room code	
Cards Information	To show the informations about cards	
Format	To format informations about cards	

4. Calling and Unlock Operation:

The DMR18 door station is a digital station with 320*240 pixels LCD screen, color CCD camera, night view LED, and digital keypad.


Visitors can call the apartment by dialing the Flat Code (apartment number) on the keypad. If they don't know the Flat Code (apartment number), they can search the name list on the screen. If the door station is in standby, visitors need to press '9#' to display the user name list. Press '#' key to scroll next/last page. and use key 1 to 8 key on each page to call the desired flat.

Residents can open the door by using their unique Unlock Code (four-digit PIN code). If the door station is in standby mode, press '#' key, then input the four-digit unlock to open the door. Please refer to part 5, section 7 (How to use code unlock function) for more detail information.

Note: If the door station works as apartment system mode, input 01~32 to call the relevant monitor. If the door station works as villa mode, input 01 to call the monitors which its code is from 00~15. Input 02 to call the monitors which its code is from 16~31. please refer to table 2.1 (working mode)


5. About Default Set:

The Default Set is very important. When the door station miss up the settings in anyway, the most quickly and easy way to solve the problem is to activate the default setting on door station. The default settings already have all the right settings for one-building system, that means the system will work normally without any additional settings.




6. Change Ring Tone:

There are 12 different ringtones. If door station runs as Debug State, you can press [1 #] --> [2] Setup --> [2] Tone Select to enter tone setting page. If it runs as Normal State, follow these steps:



7. Change Installer Code(administrator password):


The Installer Code is the password to access the door station debug State. The default Installer Code is '66666666'. Note that if the Default Set have been activated, the Installer Code will be set to default value.



In Debug State,
press '1 #' key

press '1'

press '8'



Input a new Installer Code
and then press '#' key to
confirm

8. How to use code unlock function:

Please refer to the following operations:




When the Door Station is
in standby, Press “#”

Input 4 digits Unlock
Code directly

If verified correctly,
door open

9. Change Unlcok Code:

If door station runs as Debug State, you can press “1#” to activate Tools Menu, then select “2” to enter setup page,then select 4 item.If it runs as Normal State, follow these steps:



Press “#”,Input “8002”,
then input Setup Code or
Admin Code(88888888 or
66666666 by default)

Press “4” to enter
unlock code item.

Input 4 digits number,
then press “#” to
update


10. User Card Management:

This section explains how to configure the key fob function on DMR18,The key fob is used to open the lock. Total 1000 key fobs can be registered with one door station. When swiping the fob to the door station, the distance must be less than 3 centimeter. Key Fobs must be registered on the Door station that can be used to open the door.

Register the Key Fobs:

All the registered key fobs are called User Cards/User Key Fobs. New fobs/cards need to be registered one by one to the Door station to become a valid User Card/User Key Fob; and every User Card/User Key Fob is related to a certain Monitor Address (Flat code).

When the Doors tation is standby, press [#] --> [9008] --> Password([66666666 by default]) to get into the Debug Mode Menu, then Press [1 #] --> [3] Card Manage -->[1] Add Card to get into the Add Card page. Please see the followings.



Enter Add Card menu,
and Room Code is asked.

Input Room Code

Read the card to be
authorized


Delete user cards:

Registered User Cards/Key Fobs can be deleted from the Door station,once doing the delete operation,the card/key fobs can not open the door anymore. They can also be re-registered again to become a valid User Card/User Key Fob. There are two ways to delete User Cards/ User Key Fobs:

1. Delete by card: show the unwanted card(s) when the Door station is in Delete Card Mode
2. Delete by room number: delete all the registered User Cards related to that room No.


Delete By Card:

In Debug State , Press [1 #] --> [3]
Card Manage -->[2] Delete By Card
to enter Delete by Card page.as
shown on the right, then show the
cards you want to delete one by one.



Delete by Room Number:


In Debug State , Press [1 #] --> [3]
Card Manage -->[3] Delete By M.Code
to enter Delete by M.Code page.as
shown on the right, then Input the
Room Code, press “#” to confirm; all
associated cards will be deleted.



-16-


Card information:

Enter Card Information page, and the
screen will display the authorized User
Cards count, and card read access
events count.



Format:


Enter Card Format page, a password
will be asked,input 8 digits installer
password (66666666 by default),then
press" #" key to save,format operation
is activated.all card information will be
cleared.



11. Change Door Station Language:

It's convenient to change the user interface for DMR18.Just put the config files to the SD card and by means of the digital keypad of door station,only 30 seconds is needed to update.


Step 1: Insert the SD card which is
contained config files into the SD card slot
where is at the back of the door station.
Refer to the right diagram.



Step 2:

If door station runs as Debug State, you can press “1#” to activate Tools Menu, select “2”
to enter setup page,then select 1 item.If it runs as Normal State, follow these steps:

-17-



Language code number:

8101: English	8107: Portuguese	8113: Russian
8102: French	8108: S-Chinese	8114: Slovakia
8103: Spanish	8109: T-Chinese	8115: Hungary
8104: Italian	8110: Greek	8116: Czech
8105: German	8111: Turkish	
8106: Dutch	8112: Polish	




When the door station output a long sound DI..., that means UI updating is finished.


12. Search online door stations and monitors:

"Online Search" is a very useful function that can help the installer to easily check the connectivity of all the Monitors. Please note, Online does not mean via the internet. Please refer to the followings:


Check online door stations:



Check online monitors:



Search Range: input the monitor address. For example, input the range from 01 to 05. You will see the connection status of the selected monitors.



13. Namelist function:

DMR18 is designed to have digital keypad and big TFT screen. Its namelist was shown on the screen and customer can do the calling operation through the digital keypad guided by Namelist on the screen. 2 types of namelist can be shown on the screen : DT-Config namelist and Simulate namelist.

Enter namelist page:

Press '9#' in standby mode to display the user namelist. Press '#' key to scroll next/last page. and use key 1 to 8 key on each page to call the flat you want. Please refer to the DT-Config software user instructions for configure the namelist.

Send namelist to monitors

The namelist can be sent to monitors by door station directly. Connect the door station and monitors correctly to the system. Then press # 8012 in standby mode, and input password (66666666 by default) to send namelist to all the monitors.

7. Specification

- Power supply : DC24V(Powered by DT-DPS)
- Camera Lens : 1/4 ACS 4T image sensor with DSP processor
- Power consumption : Standby 3W;Working status 9W
- Screen : 3.5 inch TFT
- Resolution : 320(R, G, B)X240 pixels
- Video signal : CCIR/EIA Optional
- Wiring : 2 wires, non-polarit